


**OPERATING INSTRUCTION**

Name-plate for doorstation **BVD-342NP** is intended for use together with doorstation **BVD-343x (BVD-344x)**, and provides back light for the names label.




- (1) - Metal housing
- (2) - Names label located behind the glass
- (3) - Back lid
- (4) - Connecting wires:

Wire colour	Destination
Colour	Supply voltage for doorstation's LEDs
White	Ground

Figure 1 - Name-plate for doorstation **BVD-342NP** appearance, destination of wires

**PARTS LIST**



**SAFETY INSTRUCTIONS**

The product does not contain voltage above **15VDC**.

**Please DO NOT**

- perform any connections or repair when the power is on
- attempt to service the product by yourself: refer all services to qualified service personnel

Take care not to spill any liquids or chemically active substances on the product.

## INSTALLATION

**For qualified installation, wiring and servicing refer to technical and commercial partners of VIZIT TM. The list of companies is given on VIZIT.EU (<http://vizit.eu/eurounion/>).**

Before installation, unscrew and take off the back lid. Take out the names label and fill it out with names of subscribers and their corresponding dialing numbers. Place back the names label over the transparent plastic sheet. Restore the back lid and tighten the screws.

**Note.** Do not place the names label directly over the glass.

In order to reduce the weather effect on the product (e.g. low temperatures, high humidity, hoarfrost, dew), and to maximize its reliability, do not locate the product in places exposed to direct weather conditions. Mounting Kit **MK-311** is recommended to protect the doorstation from rain, snow and direct sun rays.

Wall mounting of the Name-plate doorstation **BVD-342NP** is shown on Figure 2.




Figure 2 - Name-plate for doorstation **BVD-342NP** wall mounting

Wiring diagram of the Name-plate for doorstation **BVD-342NP** and Doorstation **BVD-343x (BVD-342x)** is given on Figure 3.




Figure 3 - Wiring diagram of Name-plate for doorstation **BVD-342NP** and Doorstation **BVD-343x (BVD-342x)**

## SPECIFICATIONS

- |                          |                     |
|--------------------------|---------------------|
| • Operating voltage      | <b>15 VDC</b>       |
| • Current consumption    | <b>7 mA max.</b>    |
| • Dimensions (W)x(H)x(D) | <b>86x171x10 mm</b> |
| • Weight                 | <b>0.45 kg.</b>     |

## OPERATING CONDITIONS

- |                             |                          |
|-----------------------------|--------------------------|
| • Ambient temperature range | <b>-40°C to +45°C</b>    |
| • Relative humidity of air  | <b>up 98% to at 25°C</b> |